


TELETASK

trendsetter in domotics



GUI SOFTWARE

The floor plan of your house is your control switch.

In today's modern house more and more technical functions are integrated into the domotics system. This integration guarantees that all functions are better geared to each other and furthermore makes the controls of the house available wherever you need them.

The GUI Software is a graphical user interface for a user-friendly control of the TELETASK domotics system using the floor plan of your house. Your PC, laptop or ultra mobile PC will be turned into a versatile and personal interface in no time. By simply touching your touch screen or clicking your mouse, you will be switching and dimming lights, manipulating multi-coloured LED lighting, turning the heating or cooling on and off, changing temperature settings, controlling sun blinds and curtains and any other electrical appliance or choosing your favourite scene or mood. Furthermore, TELETASK GUI offers the possibility to display images from IP cameras. Curious about the weather forecast or who has won the big game? This information too is only a click away. And last but not least, you have complete graphical freedom in preparing the

different floor plans: classic or modern, cottage or Mediterranean ... you decide what ambiance your GUI will make for you.

Extensive graphical possibilities, user-friendliness and amazing functionalities make GUI one of the most desired control solutions for the integrated house.

There is something for everyone

Your GUI can be installed on different devices: A standard PC, notebook PC, in-wall mounted panel PC with touch screen that serves as a TV, a painting or a GUI, according to your wishes. Or maybe you would rather go wireless: install your GUI on a tablet or ultra mobile PC that you carry along the house.

TELETASK

trendsetter in domotics

1

Select the area in the house

2

Select the function

3

Control the specific function



GUI Soft: easy 3-step control

Floor plans.

The appearance of your graphical control screens are defined by the used floor plans. This way the design of your house will reappear in the look of your GUI. Just hand over the desired floor plan to your electrical installer and he will turn it into a stylish GUI suiting your personal taste. The factory supplied GUI library is stacked with hundreds of icons of lamps, wall sockets, curtains, sun blinds, appliances, multi-media... and of course, should you not find the right icon for your retro 50ies lamp, you can always import your own custom made image.

Technical

Hardware

The system(s) on which you install your GUI(s) can be flawlessly integrated into the TELETASK domotics system.

In order to connect only one GUI system to the TELETASK system, use either a serial cable or a LAN connection over Ethernet.

In order to connect several GUI systems, always use a LAN connection to the TELETASK central unit.

Software

The GUI is licensed software that is dedicated to one subsystem –i.e. a desk-top PC, a panel PC... This implies that you will have to purchase a licence for each subsystem that you wish to integrate with the TELETASK domotics system (1 for 1 screen; 2 for 2; 3 for 3... etc).

A GUI is created with the GUIISOFT software. This software comes free with the PROSOFT SUITE V3.00 (and V2.80), the software that is used to parameterise the TELETASK domotics system. Your personal customised floor plans are imported into the GUI software.

Minimal system requirements

Pentium 4 PC

Windows XP or later

256 Mb RAM

Java Runtime Environment 1.5 (Comes free of charge with the GUI licence)

Order Code

TDS15100

GUI software licence